

BOOST

How to Disable Tilt Function

****For safety reasons, the chair's tilt adjustment lock should be permanently locked in the most upright position by installer prior to use****

STEP 1

Place the Tilt Adjustment knob into the locked position.

The knob will be locked when it has been pushed upward.



STEP 2

Flip the chair so it is resting on the seat.

With the Tilt Adjustment knob still in the locked position, unscrew the screws and save.



STEP 3

Zip-tie the mechanism cover to the Tilt Adjustment knob to avoid any loose parts.



STEP 4

Unscrew the two bolts to the base cover closest to the Tilt Adjustment knob.



STEP 5

Place the Tilt Adjustment knob under the base cover.



STEP 6

Screw the two bolts back into the base cover. Make sure it is tightly secured.

Your Counter Height Chair is now ready to be used!



Want a more stationary seat?

Your Counter Height Kit will have rolling casters included.

For a more stationary seat, flat feet are also available.



Maintenance & Safety

1. Make sure that the chair can only carry one person at a time.
2. Do not use the chair as a step stool or ladder.
3. Do not use the chair before all parts are properly assembled.
4. Do not use the chair unless all screws have been tightened.
5. If destroyed by outside forces or defective work, stop use of the chair until repaired.
6. For your safety, the instructions listed on this sheet must be strictly observed.